



Ensure that the leather has been cleaned with a neutral, HQ leather cleaner. Do not use cleaners containing any softening additives.



Apply **Q<sup>2</sup>LEATHERCOAT** onto dry leather with an HQ Cotton applicator pad, ensuring even coating



Let dry for at least 12 hours before use.

If in need of extra protection, reapply the product after at least one hour.